

RTSP usage with Bosch VIP Devices

www.boschsecurity.com



1 Overview

The **Real Time Streaming Protocol** (RTSP) allows live viewing of video and replay of recorded video from a BVIP encoder or IP camera with a compatible standard media player.

»Standard« in this way has the meaning of »implemented according to the RTSP standard« RFC 2326. RTSP support has been added to MPEG4 SH++ BVIP encoders and IP cameras with firmware 3.0. H.264 RTSP streaming is supported since firmware version 4.0 and with firmware version 4.10 audio support has been included. In addition, firmware version 4.10 provides ONVIF compliance (and JPEG streaming).

The Video LAN Client (VLC) or any other RTSP compatible player can be used as a test client for the RTSP connection, independent of the used platform (Windows, Macintosh, Linux, ...).



Note:

Please note that the RTP payload type which is used for H.264 video is fixed to the value 35. While parsing the RTP session H.264 video is only to be expected in this payload type.

The encoding profiles within the encoder must be set up properly to allow connections via RTSP. All supported resolutions and encoding profiles are available through RTSP.

The URL for the requested video stream may look like:

RTSP://160.10.0.1/<<parameter_string>>

The following examples assume

- ▶ a Dinion IP camera installed at the IP address 160.10.0.1
- ▶ a VideoJet X40 XF E installed at the IP address 160.10.0.40 with 4 cameras connected

The <<parameter_string>> syntax and valid parameters are described in section 3 *Available RTSP Parameters*, page 4; however one may already get a feeling for the syntax in the next chapter.

2 Examples

2.1 Setting up a live connection

Connecting to a BVIP unit is as simple as entering a URL that specifies the protocol and the unit's IP address. An RTSP connection from e.g. VLC to the Dinion IP is established by opening the **File** menu, choosing **Open network** and entering:

RTSP://160.10.0.1

This will show live video from the Dinion IP camera, using encoding stream 1. Reception of stream 2 is accomplished by handing over the parameter **inst** to the Dinion IP's RTSP server.

The RTSP server inside the Bosch IP Video unit doesn't need a web page addressed in the URL but needs the slash after the IP address followed by the question mark as a separator for the query string that carries the parameter(s). Therefore the request should look like:

RTSP://160.10.0.1/?inst=2

2.2 Setting up a replay connection



Note:

Replay of recorded video via RTSP works for locally managed recordings or centrally managed (VRM) recordings, but require VRM version 3.0 or higher and firmware version 5.70 or higher.

To establish a replay connection over RTSP the URL needs some additional parameters. The connection is set-up with the following URL:

```
RTSP://160.10.0.1/rtsp_tunnel?rec=1&rnd=718
```

This will show the recorded video of stream 1. The recording is replayed by default with normal speed (100 %) and the starting point of the session is the start time of the last recorded slice. The random number (**rnd**) in the URL is necessary to enable further actions with the recorded stream, like replay from a specific time, or search for recordings by means of RCP+. The parameter is to be interpreted as a bool value and does not reference a specific recording (for further information see chapter *Recorded video stream selection*, page 4).

NTP time mapping of the conveyed RTP timestamps is explained in section 4.4 *RTP replay timestamp, NTP time mapping*, page 22.

2.3 Selecting a camera from a multi-channel unit

Similar to the example above, an RTSP connection from VLC to the VideoJet X40 XF E is established by opening the **File** menu, choosing **Open network** and entering:

```
RTSP://160.10.0.40
```

This would show live video from the first camera on the VideoJet X40 XF E, using stream 1. The video inputs and the respective cameras are selectable through the **line** parameter. To connect to the video feed from the second camera, the URL needs look like:

```
RTSP://160.10.0.40/?line=2
```

Multiple parameters can be handed over equal to standard query string notation in an URL, separated by **&**. The order of the parameters in the query string is not relevant. An RTSP connection to the second encoding stream of camera 3 would require the following URL:

```
RTSP://160.10.0.40/?line=3&inst=2
```

2.4 Setting up a Multicast connection

Given a scenario where multiple users need to connect to one live source one multicast session is preferable to multiple unicast streams. Multicast RTSP connections are established using the **multicast** parameter. The resulting URL to join the multicast RTSP stream from the Dinion IP would be:

```
RTSP://160.10.0.1/?multicast=1
```

Similarly, joining a multicast RTSP stream from the fourth camera and the second encoding stream of the VideoJet X40 XF E is accomplished by entering the URL:

```
RTSP://160.10.0.40/?line=4  
&inst=2&multicast=1
```

2.5 Selecting the stream encoding type

Since firmware version 4.0 Bosch IP Video units allow the selection of the encoding type for the streamed video (depending on the device's encoding capabilities) with the **h26x** parameter.

The supported encoding types are:

- ▶ JPEG h26x=0
- ▶ MPEG-4 SH++ h26x=3
- ▶ H.264 h26x=4

Thus, explicitly specifying the stream encoding for an MPEG-4 SH++ stream would require the following URL:

```
RTSP://160.10.0.1/?h26x=3
```

Accordingly, a H.264 streaming request looks like:

```
RTSP://160.10.0.1/?h26x=4
```

Alternatively, JPEG streaming is requested with the following URL:

```
RTSP://160.10.0.1/?h26x=0
```

2.6 Setting up a video connection with audio

Some Bosch IP Video units are equipped with audio inputs. As an example, a VideoJet X40 XF E provides two audio inputs. Enabling an audio connection along with the video stream requires different parameters to be used (see example below).

The first parameter (**enableaudio**) enables audio in general and needs to be set to 1. The second parameter (**audio_line**) identifies the audio input that is streamed in conjunction with the video. This parameter and its values are used similarly to the **line** parameter.

For an RTSP connection that would show live video from the first camera on the VideoJet X40 XF E together with audio from the first audio input, the URL must look like:

```
RTSP://160.10.0.40/?line=1
&enableaudio=1&audio_line=1
```

Audio and video inputs are usually used together. Thus, addressing only the audio input without the video line parameter will automatically connect the corresponding video input. The following URL establishes the same video and audio connections as the previous example:

```
RTSP://160.10.0.40/?enableaudio=1
&audio_line=1
```

If a certain audio input shall be attached to a certain video input the parameters must be given accordingly. To conjoin the second audio input with the fourth video input the URL looks like:

```
RTSP://160.10.0.40/?line=4
&enableaudio=1&audio_line=1
```



Note:

Please note that in this case the **line** parameter must be provided in advance of the **audio_line** parameter. Otherwise the conjoin default mechanism would step in and the additional **line** parameter would be discarded.

For a Multicast RTSP connection with H.264 streaming from our VideoJet X40 XF E's camera 3, using the second stream, while listening to the signal from the first audio input, the URL must look like:

```
RTSP://160.10.0.40/?h26x=4
&line=3&inst=2&multicast=1
&enableaudio=1&audio_line=1
```

3 Available RTSP Parameters

3.1 General

RTSP parameters can be handed over the BVIP RTSP server by means of a **URI query string** as defined in RFC 3986 (<http://tools.ietf.org/html/rfc3986#section-3.4>).

3.2 Setup parameters

3.2.1 Live video stream selection

This parameter selects the video instance (video stream) to be retrieved through RTSP.

Parameter and values	
Parameter	inst
Values	1 = stream 1 2 = stream 2
Example	RTSP://160.10.0.1/?inst=2

3.2.2 Enable replay mode

This parameter enables the device's replay mode, which means that a recorded video stream is being streamed through RTSP.

Parameter and values	
Parameter	rec
Values	0 or 1 (as bool; enabled or disabled; default is disabled)
Example	RTSP://160.10.0.1/?rec=1

3.2.3 Recorded video stream selection

This parameter selects the recorded video stream that is to be replayed. This selection always goes along with the **rec** parameter.

Parameter and values	
Parameter	inst
Values	1 = recording 1 2 = recording 2
Example	RTSP://160.10.0.1/?inst=2&rec=1

3.2.4 Replay speed

With FW 5.90 an additional RTSP parameter for controlling the speed of a replay session has been added.

The speed is controlled in percent, where a value of 100 represents 'realtime'. Negative values represent a replay in reversed direction. This is a best effort approach and once the device is not able to catch up with a set replay speed the packets are sent out as fast as possible.

Values above 1000000 are interpreted as iFrame only mode, which allows for speed manipulation through the addition of the replay speed percentage to this value. That means that a value of 1000100 requests an iFrame only stream in realtime, whereas a value of 1001000 requests an iFrame only stream in 1000% of the realtime speed (10 x realtime).

Parameter and values	
Parameter	speed
Values	-2000 ... 2000 (replay speed as percentage of realtime; negative values trigger playback in reverse direction; 100 represents realtime) -1009000 ... -1000000 and 1000000 ... 1009000 (replay speed of an iFrame only stream; the result of 'abs(value)-1000000' is interpreted as replay (as percentage of realtime) speed of the iFrame only stream with the same mapping as above)
Examples	RTSP://160.10.0.1/?rec=1&speed=200 RTSP://160.10.0.1/?rec=1&speed=1003000

3.2.5 Seek parameter

With FW 5.90 an additional RTSP parameter for seeking to a certain point in time of a recording has been added.

The seek time is given in 'local time' of the device and is calculated in seconds since Jan. 1st 2000, midnight.

Parameter and values	
Parameter	seek
Values	number (seconds since Jan. 1st 2000;) special values: 0x0 = first available file 0xFFFFFFFF = last available file
Example	RTSP://160.10.0.1/?rec=1&seek=0x0

3.2.6 Random number

This parameter defines a random number which is needed to retrieve the RTSP session ID with the help of RCP+.

This parameter usually goes along with the **rec** parameter.

Parameter and values	
Parameter	rnd
Values	random number
Example	RTSP://160.10.0.1/?rnd=718&rec=1

3.2.7 Replay session setup

This parameter adds a generic FMTP line to the session description during the session setup for a replay stream.

By default, the SDP in the session setup does not contain an FMTP line as all the necessary parameters are transmitted in-line with the first replay packets. Some clients need this information during setup, though.

(General availability FW 6.40 and above)

Parameter and values	
Parameter	fmtp
Values	0 or 1 (as bool; false or true)
Example	RTSP://160.10.0.1/?fmtp=1

3.2.8 Establish RTSP tunnel

This parameter enables a tunneled (port 80) TCP media connection.

Setting up VLC for TCP tunneling needs adjustments of VLC's advanced options (see *Setting up VLC for RTP/TCP tunneling*, page 21).

Parameter and values	
Parameter	rtsp_tunnel
Values	
Example	RTSP://160.10.0.1/rtsp_tunnel



Note:

Please note that the **rtsp_tunnel** parameter is not part of the query string!

Furthermore, the parameter does not change the media transport mode. The media session setup (transport mode) is specified during connection setup (in the RTSP SETUP request). A brief overview of the various RTSP transport modes can be found in chapter *RTSP/RTP setup modes*, page 13.

3.2.9 Video line selection

This parameter selects the video line (for multi input devices) to be retrieved through RTSP. Since VRM version 3.10 this parameter can also be used to address a track list entry of the VRM.

Parameter and values	
Parameter	line
Values	selects the corresponding line or the corresponding track list entry of a VRM
Example	RTSP://160.10.0.1/?line=1

3.2.10 VRM track selection

This parameter is available since VRM version 3.10 and allows to select a specific TrackID from the VRM.

Parameter and values	
Parameter	trackid
Values	number (trackID as available in VRM; the list of available trackIDs needs to be known a priori)
Example	RTSP://160.10.0.1/?trackid=7

3.2.11 Enable video

This parameter enables or disables video in the RTP session. Video is enabled by default.

Parameter and values	
Parameter	enablevideo
Values	0 or 1 (as bool; false or true; default = true)
Example	RTSP://160.10.0.1/ ?enablevideo=0

3.2.12 Enable video authentication

This parameter enables and disables video authentication. The authentication itself needs to be configured via Bosch RCP+ protocol.

(General availability FW 6.32 and above)

Parameter and values	
Parameter	auth
Values	0 = no video authentication 1 = in-line authentication (the authentication packages with RTP payload type 97 are multiplex into the video session) 2 = parallel authentication (the authentication packages with RTP payload type 97 are streamed in a separate RTSP session)
Example	RTSP://160.10.0.1/?auth=1

3.2.13 Enable audio

This parameter enables or disables audio in the RTP session. Audio is disabled by default. By enabling audio without specifying the **audio_mode** parameter, the G.711 audio encoding type is used as default.

Parameter and values	
Parameter	enableaudio
Values	0 or 1 (as bool; false or true; default = true)
Example	RTSP://160.10.0.1/ ?enableaudio=1

3.2.14 Select the video encoding type

This parameter selects the video encoding type for the RTP session.

Parameter and values	
Parameter	h26x
Values	0 = JPEG 4 = H.264 3 = MPEG-4 SH++ [where available]
Example	RTSP://160.10.0.1/?h26x=0

3.2.15 Select the audio encoding type

This parameter selects the audio encoding type for the RTP session.

Parameter and values	
Parameter	audio_mode
Values	0 = AAC 1 = G.711 2 = L16
Example	RTSP://160.10.0.1/ ?audio_mode=0

3.2.16 Enable ONVIF metadata

This parameter enables or disables ONVIF IVA events. If no metaline is specified, video line 1 is taken as default.

Parameter and values	
Parameter	meta
Values	0 or 1 (as bool; false or true)
Example	RTSP://160.10.0.1/?meta=1

3.2.17 Disable ONVIF replay header extension

This parameter enables or disables the addition of the ONVIF replay header extension for RTSP replay sessions (see also chapter *RTP replay timestamp, NTP time mapping*, page 22).

Parameter and values	
Parameter	onvifhdr
Values	0 or 1 (as bool; false or true)
Example	RTSP://160.10.0.1/?rec=1&onvifhdr=0

3.2.18 Select line for ONVIF metadata

This parameter selects the input line for the creation of ONVIF IVA events.

Parameter and values	
Parameter	metaline
Values	number (input line for the creation of ONVIF metadata; default is the video line line)
Example	RTSP://160.10.0.1/?metaline=1

3.2.19 Enable Bosch VCA data

This parameter enables or disables the transmission of Bosch VCA data.

Parameter and values	
Parameter	vcd
Values	0 or 1 (as bool; false or true)
Example	RTSP://160.10.0.1/?vcd=1

3.3 Multicast parameters

3.3.1 Preliminary note

The configured multicast settings on a device's web page used to be independent from the RTSP multicast settings, since the RTSP stack merely just acted as a RTP relay on the device and did not synchronize with the RCP+ connections or settings.

Practically this led to some issues in networks where RCP+ and RTSP multicast streams were pulled and hence a synchronization mechanism between the web page settings of the device and the RTSP multicast group was introduced. That means that the device is using the configured multicast group and port for video.

The adjacent audio port is the video port + 2.

A JPEG session will use the settings for video stream 1 and the port is the video port + 8.

This synchronization was introduced with FW 5.90 (5.72 for CPP3 devices) and is available from thereon.

3.3.2 Enable multicast

This parameter enables multicast streaming on the Bosch VIP devices.

Parameter and values	
Parameter	multicast
Values	0 or 1 (as bool; false or true)
Example	RTSP://160.10.0.1/?multicast=1

3.3.3 Video port

This parameter sets the port, which is used for the multicast video session.

Parameter and values	
Parameter	mc_port_video
Values	number (selects video multicast port)
Example	RTSP://160.10.0.1/ ?mc_port_video=1996

3.3.4 Video IP address

This parameter sets the IP address, which is used for the multicast video session.

Parameter and values	
Parameter	mc_group_video
Values	IP address string (selects video multicast address)
Example	RTSP://160.10.0.1/ ?mc_group_video=239.0.0.10

3.3.5 Audio port

This parameter sets the port, which is used for the multicast audio session.

Parameter and values	
Parameter	mc_port_audio
Values	number (selects audio multicast port)
Example	RTSP://160.10.0.1/ ?mc_port_audio=1998

3.3.6 Audio IP address

This parameter sets the IP address, which is used for the multicast audio session.

Parameter and values	
Parameter	mc_group_audio
Values	IP address string (selects audio multicast address)
Example	RTSP://160.10.0.1/ ?mc_group_audio=239.0.0.10

3.3.7 Metadata port

This parameter sets the port, which is used for the multicast metadata session.

Parameter and values	
Parameter	mc_port_meta
Values	number (selects metadata multicast port)
Example	RTSP://160.10.0.1/ ?mc_port_meta=2000

3.3.8 Metadata IP address

This parameter sets the IP address, which is used for the multicast metadata session.

Parameter and values	
Parameter	mc_group_meta
Values	IP address string (selects metadata multicast address)
Example	RTSP://160.10.0.1/ ?mc_group_meta=239.0.0.10

3.3.9 Retriggering the multicast connection

RTSP multicast connections need a retrigger event to keep the connection alive. This behavior can be disabled by setting **mcRetrigger=0** in the RTSP URL for environments where no keep-alive messages are sent. Otherwise the connection times out after 1 minute.

Any RTSP request can be used as a keep-alive. Usually an OPTIONS or GET_PARAMETER request is a good choice for a keep-alive message. Also an RTCP ReceiverReport is interpreted as a keep-alive packet; RTCP RRs are only available in unicast sessions, though.

If the device is set to 'not expect retrigger packets' a connection needs to be shut down explicitly with an RTSP TEARDOWN request. If such a request is not sent, the connection is kept open 'forever'. For this reason the **mcRetrigger** parameter should only be used when its intention is clear and no other way of retriggering the connection is available.


With FW 5.90 and FW 5.73 the retrigger issued with VLC-based implementations are solved inside the devices' RTSP server and this parameter should be considered as obsolete.

3.4 Transcoder parameters

Since FW 5.90 some RTSP parameters to control the transcoder functionality have been added to the transcoder interface and in addition also an RTSP input interface was added. Such an interface allows the transcoder to act as an RTSP client and basically transcode any RTSP/RTP H.264 video source.

The following picture displays the general building blocks of such a scenario.

Parameter and values	
Parameter	mcRetrigger
Values	0 or 1 (as bool; false or true)
Example	RTSP://160.10.0.1/ ?mcRetrigger=1



Available transcoder parameters are as follows:

3.4.1 Enable the transcoder

This parameter enables the transcoder (e.g. in case a transcoder instance of a Video Jet X20/X40 XFE) is used.

Parameter and values	
Parameter	tc
Values	0 or 1 (as bool; enabled or disabled; default = enabled on transcoding devices, disabled on non transcoding devices)
Example	RTSP://160.10.0.1/?tc=1

3.4.2 Preset

This parameter selects the transcoder preset for the current replay session.

Parameter and values	
Parameter	preset
Values	1 ... 8 (selects one of the 8 transcoder presets; default = 1)
Example	RTSP://160.10.0.1/?preset=3

3.4.3 Bitrate

This parameter sets the bitrate that is used by the transcoder for the current replay session.

Parameter and values	
Parameter	kbps
Values	number (sets the bitrate in kbps)
Example	RTSP://160.10.0.1/?kbps=500

3.4.4 Frame skip

This parameter sets the skip rate that is used by the transcoder for the current replay session. A skip ratio of 1 means that no frame is skipped and the transcoded video stream uses the same frame rate as the original stream. A skip rate of 3 means that every 3rd frame is transcoded; hence the resulting frame rate is only 1/3rd of the original frame rate.

Parameter and values	
Parameter	skip
Values	number (e.g. 1 = encode every 1st frame, 3 = encode every 3rd frame, the resulting frame rate is 1/3rd of the original frame rate)
Example	RTSP://160.10.0.1/?skip=3

3.4.5 Video format

This parameter sets the video format of the transcoded video stream.

Parameter and values	
Parameter	fmt
Values	0 = do not change the video format (default) 1 = small (~CIF) 3 = large (~4CIF) 720 = 720p 1080 = 1080p
Example	RTSP://160.10.0.1/?fmt=3

3.4.6 GOP size

This parameter controls the group of picture (GOP) size by setting the frame distance for sending intra frames in the transcoded video stream.

Parameter and values	
Parameter	ifrmdist
Values	number (distance of consecutive intra frames; default = 60)
Example	RTSP://160.10.0.1/?ifrmdist=30

3.4.7 Timestamping

This parameter enables display stamping of the time-stamp of the recorded data. That feature only works if Bosch SEI information or the ONVIF header extension is available in the recorded transcoder input.

Parameter and values	
Parameter	timestamp
Values	0 or 1 (as bool; enabled or disabled; default = disabled)
Example	RTSP://160.10.0.1/?timestamp=1

3.4.8 ROI horizontal position

This parameter controls the horizontal center of gravity of a region of interest (ROI) stream being requested from the transcoder. The coordinate system is normalized in a value range from 0 to 0x8000.

Parameter and values	
Parameter	roiupos
Values	0 ... 0x8000 (in a normalized coordinate system; horizontal 0 is located on the left side of the video image; default = 0x4000 which represents the horizontal center of the image)
Example	RTSP://160.10.1.100/?roiupos=0x4000

3.4.9 ROI vertical position

This parameter controls the vertical center of gravity of a region of interest (ROI) stream being requested from the transcoder. The coordinate system is normalized in a value range from 0 to 0x8000.

Parameter and values	
Parameter	roivpos
Values	0 ... 0x8000 (in a normalized coordinate system; vertical 0 is located on the bottom of the video image; default = 0x4000 which represents the vertical center of the image)
Example	RTSP://160.10.0.1/ ?roivpos=0x4000

3.4.10 ROI size

This parameter controls the relative size of a region of interest stream being requested from the transcoder. The size is given in relative values in a value range from 0 to 0x8000, where a value of 0 means 'no region of interest'.

Parameter and values	
Parameter	roisize
Values	0 ... 0x8000 (as relative size; default = 0 which means no ROI, e.g. 0x2000 = ROI size is 25% of the original size)
Example	RTSP://160.10.0.1/ ?roisize=0x2000

3.4.11 RTSP input source

This parameter enables the RTSP client of the transcoder, which is requesting the specified URL as the transcoder's input.

Parameter and values	
Parameter	url
Values	RTSP URL to connect the transcoder's RTSP client to the source (http escaped string)
Example	Connection to the following url: 'rtsp://user:u@160.10.0.200' RTSP://160.10.0.1/ ?url=rtsp%3A%2F%2Fuser%3A %40160.10.0.200

3.4.12 Advanced example

Let's assume an RTSP/RTP video source that is accessible via:

rtsp://user:u@160.10.0.200

should be transcoded on the transcoder device

160.10.1.100

with the following transcoder output parameters:

- ▶ video resolution: 4CIF
- ▶ video bit rate: 500 kbps
- ▶ connection: TCP tunneled

The complete RTSP request that needs to be sent to the encoder would look like:

```
RTSP://160.10.1.100/rtsp_tunnel  
?tc=1&fmt=3&kbps=500&fmt=3  
&url=rtsp%3A%2F%2Fuser%3Au%40160.10.0.200
```

4 Technical Details

4.1 RTSP/RTP setup modes

According to the relevant RFC 2326 (<http://www.ietf.org/rfc/rfc2326.txt>) the Real Time Streaming Protocol, or RTSP is:

»... an application-level protocol for control over the delivery of data with real-time properties. RTSP provides an extensible framework to enable controlled, on-demand delivery of real-time data, such as audio and video. Sources of data can include both live data feeds and stored clips. This protocol is intended to control multiple data delivery sessions, provide a means for choosing delivery channels such as UDP, multicast UDP and TCP, and provide a means for choosing delivery mechanisms based upon RTP (RFC 1889).«


That means that the protocol specified various ways of setting up media connections over UDP or TCP media channels with a great flexibility but in turn also with some complexity. The following section is supposed to remove most of the complexity since it describes the relevant scenarios and features that are needed and taken into account when a media-client is interfacing with the Bosch BVIP RTSP server.

The RTSP session is referred to as the control session and uses TCP as transport protocol, whereas the RTP (<http://www.ietf.org/rfc/rfc3550.txt>) session is referred to as media session and by default uses UDP. The typical RTSP server port is 554 and the media ports are negotiated during the session setup process. In a standard setup a media session uses 2 ports. The port-pair starts with an even port for the media session and is followed by an odd port for the RTCP (RTP Control Protocol: used for connection quality reporting and synchronization between different media sessions) information. That means that media ports are dynamically allocated and used but only one control port (RTSP port) is acquired.

In addition to the 'regular' session setup with the RTSP/TCP connection and the RTP/UDP connection RTSP also offers the possibility to fully use TCP when needed (mostly when the network topology doesn't allow for UDP streaming). Setting the media session to use TCP instead of UDP is accomplished by changing the 'transport' parameter during the session setup. This is a feature that needs to be requested by the client and therefore (see following section 4.3) it needs to be enabled in the media-client. Such a setup is referred to as »RTP over RTSP« or »Interleaved RTSP« mode.

Typical use cases and control flow messages are depicted in the following charts. For a better understanding some of the charts are extended with some »Wireshark« screenshots that show a 'real-world' communication flow.

4.1.1 RTP/UDP setup



A typical trace in »Wireshark« looks like:

Source	Destination	Protocol	Length	Info
160.10.125.250	160.10.125.55	RTSP	169	OPTIONS rtsp://160.10.125.55/ RTSP/1.0
160.10.125.55	160.10.125.250	RTSP	145	Reply: RTSP/1.0 200 OK
160.10.125.250	160.10.125.55	RTSP	195	DESCRIBE rtsp://160.10.125.55/ RTSP/1.0
160.10.125.55	160.10.125.250	RTSP/SDP	431	Reply: RTSP/1.0 200 OK, with session description
160.10.125.250	160.10.125.55	RTSP	224	SETUP rtsp://160.10.125.55/video RTSP/1.0
160.10.125.55	160.10.125.250	RTSP	213	Reply: RTSP/1.0 200 OK
160.10.125.250	160.10.125.55	RTSP	211	PLAY rtsp://160.10.125.55/ RTSP/1.0
160.10.125.55	160.10.125.250	RTSP	108	Reply: RTSP/1.0 200 OK
160.10.125.250	160.10.125.55	RTSP	196	TEARDOWN rtsp://160.10.125.55/ RTSP/1.0
160.10.125.55	160.10.125.250	RTSP	108	Reply: RTSP/1.0 200 OK


The requested media transport configuration can be identified in the **SETUP** request that is sent from the client to the server:

34805	236.485900000	160.10.125.55	160.10.125.250	RTSP/SDF	431	Reply: RTSP/1.0
34822	236.508218000	160.10.125.250	160.10.125.55	RTSP	224	SETUP rtsp://160
34826	236.509922000	160.10.125.55	160.10.125.250	RTSP	213	Reply: RTSP/1.0

Frame 34822: 224 bytes on wire (1792 bits), 224 bytes captured (1792 bits)

- Ethernet II, Src: Hewlett_3a:8a:60 (64:31:50:3a:8a:60), Dst: VcsVideo_7a:c8:7a (00:07:5
- Internet Protocol Version 4, Src: 160.10.125.250 (160.10.125.250), Dst: 160.10.125.55 (1
- Transmission Control Protocol, Src Port: 60522 (60522), Dst Port: rtsp (554), Seq: 257,
- Real Time Streaming Protocol
 - Request: SETUP rtsp://160.10.125.55/video RTSP/1.0\r\n
 CSeq: 4\r\n
 User-Agent: LibVLC/2.0.1 (LIVE555 Streaming Media v2011.12.23)\r\n
 Transport: RTP/AVP;unicast;client_port=55650-55651\r\n

4.1.2 RTP/TCP setup



The according RTSP **SETUP** section to enable a TCP media connection looks like depicted below:


542	3.608777000	160.10.125.55	160.10.125.250	RTSP/SDP	431	Reply: RTSP/1.0 200 OK, with session descri
543	3.609639000	160.10.125.250	160.10.125.55	RTSP	220	SETUP rtsp://160.10.125.55/video RTSP/1.0
546	3.611041000	160.10.125.55	160.10.125.250	RTSP	181	Reply: RTSP/1.0 200 OK

```


3 Frame 543: 220 bytes on wire (1760 bits), 220 bytes captured (1760 bits)
3 Ethernet II, Src: Hewlett_3a:8a:60 (64:31:50:3a:8a:60), Dst: vcsvideo_7a:c8:7a (00:07:5f:7a:c8:7a)
3 Internet Protocol Version 4, Src: 160.10.125.250 (160.10.125.250), Dst: 160.10.125.55 (160.10.125.55)
3 Transmission Control Protocol, Src Port: 61025 (61025), Dst Port: rtsp (554), Seq: 257, Ack: 469, Len: 166
3 Real Time Streaming Protocol
  Request: SETUP rtsp://160.10.125.55/video RTSP/1.0\r\n
    Cseq: 4\r\n
    User-Agent: LibVLC/2.0.1 (LIVE555 streaming Media v2011.12.23)\r\n
    Transport: RTP/AVP/TCP;unicast;interleaved=0-1\r\n
  
```

4.1.3 RTP/UDP tunneling setup

```
rtsp://<ip>:80/rtsp_tunnel?<request string>
```



4.1.4 RTP multicast setup



A typical RTSP request for a multicast connection with a multicast group (225.5.5.5) and a multicast port (6666) that was specified by the client is shown in the **DESCRIBE** request example below:

453	2.427232000	160.10.125.250	160.10.125.250	RTSP	143	Reply: RTSP/1.0 200 OK
454	2.427383000	160.10.125.250	160.10.125.55	RTSP	251	DESCRIBE rtsp://160.10.125.55/?multicast=1
462	2.444800000	160.10.125.55	160.10.125.250	RTSP/SDP	436	Reply: RTSP/1.0 200 OK, with session descr
465	2.446558000	160.10.125.250	160.10.125.55	RTSP	281	SETUP rtsp://160.10.125.55/?multicast=1&mc
468	2.448120000	160.10.125.55	160.10.125.250	RTSP	196	Reply: RTSP/1.0 200 OK

```

Frame 454: 251 bytes on wire (2008 bits), 251 bytes captured (2008 bits)
Ethernet II, Src: Hewlett_3a:8a:60 (64:31:50:3a:8a:60), Dst: VcsVideo_7a:c8:7a (00:07:5f:7a:c8:7a)
Internet Protocol Version 4, Src: 160.10.125.250 (160.10.125.250), Dst: 160.10.125.55 (160.10.125.55)
Transmission Control Protocol, Src Port: 61216 (61216), Dst Port: rtsp (554), Seq: 172, Ack: 92, Len: 197
Real Time Streaming Protocol
  Request: DESCRIBE rtsp://160.10.125.55/?multicast=1&mc_group_video=225.5.5.5&mc_port_video=6666 RTSP/1.0\r\n
    Cseq: 3\r\n
    User-Agent: LibVLC/2.0.1 (LIVE555 Streaming Media v2011.12.23)\r\n
    Accept: application/sdp\r\n
    \r\n

```

The RTSP server replies with a description of the session that is currently being set-up. The session description protocol (SDP) is used for this purpose and amongst other necessary information the session's destination address and media ports are conveyed in the SDP string:

454	2.427383000	160.10.125.250	160.10.125.55	RTSP	251	DESCRIBE rtsp://160.10.125.55/?mult
462	2.444800000	160.10.125.55	160.10.125.250	RTSP/SDP	436	Reply: RTSP/1.0 200 OK, with sessio
465	2.446558000	160.10.125.250	160.10.125.55	RTSP	281	SETUP rtsp://160.10.125.55/?multica
468	2.448120000	160.10.125.55	160.10.125.250	RTSP	196	Reply: RTSP/1.0 200 OK

```

Frame 462: 436 bytes on wire (3488 bits), 436 bytes captured (3488 bits)
Ethernet II, Src: VcsVideo_7a:c8:7a (00:07:5f:7a:c8:7a), Dst: Hewlett_3a:8a:60 (64:31:50:3a:8a:60)
Internet Protocol Version 4, Src: 160.10.125.55 (160.10.125.55), Dst: 160.10.125.250 (160.10.125.250)
Transmission Control Protocol, Src Port: rtsp (554), Dst Port: 61216 (61216), Seq: 92, Ack: 369, Len: 382
Real Time Streaming Protocol
  Response: RTSP/1.0 200 OK\r\n
    Cseq: 3\r\n
    Cache-control: no-cache\r\n
    Content-type: application/sdp
    Content-length: 277
    \r\n
  Session Description Protocol
    Session Description Protocol Version (v): 0
    Owner/Creator, Session Id (o): - 0 0 IN IP4 160.10.125.55
    Session Name (s): LIVE VIEW
    Connection Information (c): IN IP4 225.5.5.5
    Time Description, active time (t): 0 0
    Session Attribute (a): control:*
    Media Description, name and address (m): video 6666 RTP/AVP 35
    Media Attribute (a): rtpmap:35 H264/90000
    Media Attribute (a): control:video
    Media Attribute (a): recvonly
    Media Attribute (a): ftmp:35 packetization-mode=1;profile-level-id=4d001f;sprop-parameter-sets=Z00AH5pr

```

These session parameters are used in the **SETUP** request by the client and confirmed in the **SETUP** reply from the server:

Time	Source IP	Destination IP	Protocol	Length	Details
462	2.444800000	160.10.125.55	RTSP/554	430	Reply: RTSP/1.0 200 OK, with session description
465	2.446558000	160.10.125.250	RTSP	281	SETUP rtsp://160.10.125.55/?multicast=1&mc_g
468	2.448120000	160.10.125.55	RTSP	196	Reply: RTSP/1.0 200 OK

```

Frame 465: 281 bytes on wire (2248 bits), 281 bytes captured (2248 bits)
Ethernet II, Src: Hewlett-_3a:8a:60 (64:31:50:3a:8a:60), Dst: vcsvideo_7a:c8:7a (00:07:5f:7a:c8:7a)
Internet Protocol Version 4, Src: 160.10.125.250 (160.10.125.250), Dst: 160.10.125.55 (160.10.125.55)
Transmission Control Protocol, Src Port: 61216 (61216), Dst Port: rtsp (554), Seq: 369, Ack: 474, Len: 227
Real Time Streaming Protocol
  Request: SETUP rtsp://160.10.125.55/?multicast=1&mc_group_video=225.5.5.5&mc_port_video=6666/video RTSP/1.0\r\n
  CSeq: 4\r\n
  User-Agent: LibVLC/2.0.1 (LIVE555 Streaming Media v2011.12.23)\r\n
  Transport: RTP/AVP;multicast;client_port=6666-6667\r\n

```

Time	Source IP	Destination IP	Protocol	Length	Details
462	2.444800000	160.10.125.55	RTSP/554	430	Reply: RTSP/1.0 200 OK, with session description
465	2.446558000	160.10.125.250	RTSP	281	SETUP rtsp://160.10.125.55/?multicast=1&mc_g
468	2.448120000	160.10.125.55	RTSP	196	Reply: RTSP/1.0 200 OK

```

Frame 468: 196 bytes on wire (1568 bits), 196 bytes captured (1568 bits)
Ethernet II, Src: vcsvideo_7a:c8:7a (00:07:5f:7a:c8:7a), Dst: Hewlett-_3a:8a:60 (64:31:50:3a:8a:60)
Internet Protocol Version 4, Src: 160.10.125.55 (160.10.125.55), Dst: 160.10.125.250 (160.10.125.250)
Transmission Control Protocol, Src Port: rtsp (554), Dst Port: 61216 (61216), Seq: 474, Ack: 596, Len: 196
Real Time Streaming Protocol
  Response: RTSP/1.0 200 OK\r\n
  CSeq: 4\r\n
  Session: 20a13cb51d76527;timeout=60
  Transport: RTP/AVP;multicast;destination=225.5.5.5;port=6666-6667;mode=PLAY\r\n

```

4.2 RTP keep-alive/timeout


To avoid 'loose' media sessions a default timeout of 60 seconds is used in the RTSP server, which means that a media session is closed after 60 seconds without an indication (keep-alive message) of a client still listening to the session.

In unicast scenarios RTCP Receiver Reports (RR) or any RTSP command serves as keep-alive message, whereas in multicast sessions only the RTSP commands are applicable to keep a session up and running.

Any RTSP command from a client is interpreted as a 'sign of live' at server side but the usual command is the RTSP **OPTIONS** command since it does not interfere with active media sessions.

4.3 Setting up VLC for RTP/TCP tunneling

In order to use TCP tunneling some settings have to be checked in VLC.



- Start the VLC.
- Choose **Preferences** from the **Tools** menu. The **Preferences** window opens.
- Switch the radio button at the bottom left side from **Simple** to **All** in order to show all settings.
- In the **Input/Codecs** section click on **Demuxers**.
- Click on **RTP/RTSP**.
- Check the box **Use RTP over RTSP (TCP)**. This option sets the media session to be TCP; this is accomplished by multiplexing the RTP data into RTSP packets)
- Check the box **Tunnel RTSP and RTP over HTTP**. This option is the option to switch from the default RTSP port to a tunnel port; by default this is port 80.
- Click on **Save** to save the new settings and to close the window.

4.4 RTP replay timestamp, NTP time mapping

In order to allow clients to report a stable and accurate timestamp for each frame played back regardless of the direction of playback, it is necessary to associate an absolute timestamp with each packet, or each group of packets with the same RTP timestamp (e.g. a video frame).

This is achieved using an RTP header extension containing an NTP timestamp and some additional information also useful for replay.

The replay mechanism uses the extension ID 0xABAC (= 43948) for the replay extension.

The screenshot shows a captured RTP replay packet which uses the referred RTP header extension.

The screenshot shows a Wireshark capture of an RTP packet. The packet list pane shows a series of RTP packets. The packet details pane shows the structure of the RTP packet, including the RTP header and several header extensions. A callout bubble highlights the 'Defined by profile' field, which is set to 43948. Other fields in the callout include 'Type: Unassigned', 'Reference number: 68', 'Extended sequence number: 65604', 'Timestamp: 117045', 'Synchronization source identifier: 0xffffffff (4294967295)', and 'Defined by profile: 43948'. The packet bytes pane shows the raw data of the packet, with the payload starting at offset 32.

Defined by profile:

43948 = 0xABAC

Header extension:

3573983019 = NTP time: seconds from Jan 1st, 1900

343597384 = NTP time: fraction of seconds

In this example the time is

3573983019.343597384 seconds since Jan 1st, 1900

= April 3rd, 2013 @ 13:03:39 (343597384 / 2 ^ 32) UTC