

BVMS - Deployment guide

Verhaeg Mario (BT-SC/PAS4-MKP) 18 February, 2020 Author:

Date:

1	Document information	3				
1.1	1 Version history	3				
2	Introduction	4				
2.1	1 General	4				
3	BVMS Functionality	5				
4	System requirements	7				
5	Content of the installation package	8				
6	Setup process	9				
6.1	1 Installation of the logbook	9				
6.2	2 Firewall configuration	10				
6.3	3 Repair / Modify / Remove	10				
6.4	4 No-touch deployment package	10				
7	Patches	11				
8	Languages	12				
9	Logfiles	13				
10	Commandline options	14				
11	1 Examples 16					

BVMS - Deployment guide 3 of 16

1 Document information

Project	BVMS 10.0		
Reference	n/a		
Version	13		
Last modified			

1.1 Version history

Date	Version	Description
2020-02-18	BVMS 10.0.1	Added automatic firewall configuration.

BVMS - Deployment guide 4 of 16

2 Introduction

This document describes the installation package for BVMS and is version independent. Operating system support of the specific BVMS version is listed in the BVMS release notes.

2.1 General


The BVMS installation package is distributed by ZIP file from our product download web page and comes with all components that are required to deploy the BVMS on the target system. The installation package is based on InstallShield technology.

Windows Installer V.4.5 or later is required. The setup requires administrative rights.

BVMS - Deployment guide 5 of 16

3 BVMS Functionality

The BVMS installation consists of the following installable components:



The normal installation process, using the graphical user interface, the following components can be selected:

- · Management Server (including Enterprise functionality)
 - · SSH Service
- · Configuration Client
- · Operator Client
- · Cameo SDK
 - · Cameo SDK manual and samples
- BVMS SDK
- Mobile Video Service (MVS)
- Video Recording Manager (VRM)
- · Secondary Video Recording Manager (SEC_VRM)
- Video Streaming Gateway (VSG)

Components that are not selectable and visible during the installation process are implicitly required to run the program and are installed automatically:

- The Core component is required by the Management Server, Operator Client, Configuration Client, NVR and Cameo SDK.
- · VSDK (Video SDK) is required by Client, ConfigClient, Server, MVS and Cameo SDK.
- The ExportPlayer is installed when Server or OpClient is selected. It installs the binaries for the native video player for exported video. The binaries can be exported together with the exported video. No further installation is required to run the Export Player, it can run directly from the exported folder.

Components can be dependent on each other and will be automatically selected (for example, the BVMS SDK feature is required by Server, Operator Client, Configuration Client, and Cameo SDK) when running the setup in interactive mode with user interface. Please note that all components (also dependent components) must be specified when running in silent mode from command line by using the "ADDLOCAL" property (find examples at the end of the document).

Warning

Installing a VRM and MVS on the same system is not possible and will not be supported.

BVMS - Deployment guide 6 of 16

When updating the system, the feature selection dialogue can be skipped by using the "Update now" button on the welcome dialogue. All existing features will be updated then.

Warning

When upgrading the system silently by command line without changing the existing features, the ADDLOCAL property should not be used. Otherwise features not specified in the ADDLOCAL property will get un-installed.

BVMS - Deployment guide 7 of 16

4 System requirements

To run BVMS the following 3^{rd} party prerequisites are required per component. All prerequisites are checked and installed on demand when running the Setup.exe.

Feature/Prerequisite	Purpose	All	Server	SQL_S erver	OpClie nt	Cameo SDK	Config Client	MVS
Service Handler	Stops all BVMS Services before installation/ upgrade	X						
Logging Directory	Creates logging directory	X						
.NET Framework 4.7.2	Support for managed code	X						
*DWF Viewer (Autodesk Design Review 2009)	Display DWF maps				X		X	
VC++ Runtime VC80/90/110/120/140	Support for C/C++ code	X						
OPC Core Components	BIS Connection		X					
SQL Server 2017 SP1 Express	Logbook Database			X				
Windows Desktop Experience	Video Features for Windows Server 2008				X			X
Media Foundation for Server 2012	Windows features for image decoding				X			X
Install and configure IIS	Web server for MVS							Х

BVMS - Deployment guide 8 of 16

5 Content of the installation package

The following folder structure and content can be found on the BVMS installation media:

Root:

- · Setup.exe
- Setup.ini: keeps information to control the setup (e.g. command line for the msi)
- · Language specific .ini files

BVMS folder:

- · BVMS.msi: the Microsoft installer package
- · Several compressed installation files (.cab) used by the msi
- Several .mst files (transform files) to support different languages for the setup

ISSetupPrerequisites folder:

All prerequisites required to install BVMS organized by sub-folders.

NoTouchDeployment folder:

Setup.exe

Contains a reduced installation package to update BVMS Clients only via No-Touch-Deployment. This package is
used to update clients automatically when an update is required. It is available on the server and will be
automatically uploaded to clients and started when the server version has changed.

The No-Touch-Deployment package only contains the following features:

- Core
- · Config Collector
- · Operator Client
- · Configuration Client
- BVMS SDK
- VSDK

The execution of the setup requires administrative rights.

BVMS - Deployment guide 9 of 16

6 Setup process

The setup process requires administrative rights and will be started by the "Setup.exe". The so called bootstrapper wraps the installer package (MSI), checks system conditions and installs prerequisites that are required by all features (refer to the table above). Before any system changes are performed, all BVMS related services and applications are shutdown as the very first action. Next the Windows Installer Package "BVMS.msi" is called by the Setup.exe and additional system checks are performed:

- Is the setup started on a supported operating system?
- · Is DiBos installed?
- · Is the CameoSDK installed?
- · Is the NVR Archive Player installed?

When a system check fails, the installation will be aborted with a corresponding error message.

A graphical user interface (GUI) will lead the user through the setup process:

- · License agreement
- · Selection of destination folder
- · SNMP activation
- · Feature selection
- IIS configuration
- · Firewall configuration

Dependent on the feature selection additional feature prerequisites are installed. Finally the installer copies/replace files and performs custom actions to deploy the BVMS. Upon a successful installation the system needs to be re-booted. In case of a setup error a rollback is performed and the initial installation state is restored depending on the actual progress. The installation of prerequisites cannot be reverted and must be un-installed automatically.

6.1 Installation of the logbook

The logbook feature is automatically installed together with the server feature. It is hosted in an SQL database and therefore requires SQL server installed as prerequisite. The database schema is created during the setup by a custom action. In case of an issue with the database creation (for example, SQL server not installed, service stopped, busy etc.) the following dialogue with a specific error text is displayed:



The user can select how to proceed:


- · Abort: Cancel the setup.
- Retry: Retry the logbook schema creation. If an issue with the SQL server can be fixed immediately, the logbook creation can be retried.
- Ignore: Ignore failed logbook schema creation and proceed with the setup. The setup can be re-started in repair mode at a later point in time when e.g. SQL server is fixed.

Note

The BVMS server can be operated without running SQL logbook. No event information will be stored, starting the management server may take longer then expected, and activating the configuration may take longer then expected.

BVMS - Deployment guide 10 of 16

6.2 Firewall configuration



The firewall configuration dialog is a fixed step in the setup process and will allow automatic configuration of all required firewall settings to run BVMS.

The applied rules and settings can be found in the readable command script file "C:\Program Files\Bosch\VMS\bin\FirewallConfig.cmd".

A warning message will be displayed if the configuration fails:



Note

The firewall rules that have been applied with the setup cannot be reverted and must be manually changed/removed if required.

6.3 Repair / Modify / Remove

Removal of the product of the can be accessed through the Control Panel > Programs and Features. Modifying and repairing the installation requires the original setup media by starting the Setup.exe.

6.4 No-touch deployment package

The execution of the No-Touch-Deployment package during an automatic update of clients, is performed with a reduced user interface. It will also update the prerequisites, if required. No user interaction is required.

Note

It is not recommended to run the BVMS.msi directly, since system requirements are not checked and prerequisites will not be installed or updated. This may lead to unpredictable results.

BVMS - Deployment guide 11 of 16

7 Patches

Bug fixes and small updates are usually distributed as Microsoft patches and can be downloaded from the www.boschsecurity.com website. The patch package must be installed according to the Microsoft patch process (just double click if no further options are required). A read-me file that comes with the patch will give detailed information.

BVMS - Deployment guide 12 of 16

8 Languages

The Bosch VMS Setup supports the following languages:

- English
- Arabic
- · Chinese (traditional, simplified)
- Czech
- · Danish
- Dutch
- Finnish
- French
- German
- Greek
- Hungarian
- Italian
- Japanese
- Korean
- Norwegian
- Polish
- · Portuguese (Portugal)
- Russian
- Spanish
- · Swedish
- Thai
- Turkish
- Vietnamese
- · Hebrew (on request)

Based on the operating system language, the setup language is automatically selected.

BVMS - Deployment guide 13 of 16

9 Logfiles

The Windows Installer package (MSI) writes a logfile by default:

"%PROGRAMDATA%\Bosch\VMS\Log\BVMS_Setup_V.w.x.y.z.log"

(e.g. C:\ProgramData\Bosch\VMS\Log\BVMS_Setup_V.7.5.0.123.log)

This logfile keeps all information from the Windows Installer (msiexec.exe) in debug mode. Logging for the Setup.exe is not active by default, but can be activated by command line:

Setup.exe /debuglog<logfile name>

(e.g. Setup.exe /debuglog"C:\<Path>\setupexe.log")

BVMS - Deployment guide 14 of 16

10 Commandline options

The Setup.exe and BVMS.msi support various command line arguments.

/s: silent mode

The command *Setup.exe* /s runs the installation in silent mode, by default based on the responses contained in a response file called Setup.iss in the same directory. (Response files are created by running Setup.exe with the /r option). The command *Setup.exe* /s also suppresses the Setup.exe initialization window for a Basic MSI installation program, but it does not read a response file. To run a Basic MSI product silently, run the command line *Setup.exe* /s /v/qn. To specify the values of public properties for a silent Basic MSI installation, you can use a command such as:

Setup.exe /s /v"/qn INSTALLDIR=D:\Destination".

/a: administrative installation

The /a option causes Setup.exe to perform an administrative installation. An administrative installation copies (and uncompresses) your data files to a directory specified by the user, but it does not create shortcuts, register COM servers, or create an uninstallation log.

/v: pass arguments to MSIExec

The /v option is used to pass command-line options and values of public properties through to Msiexec.exe.

/x: Uninstall mode

The /x option causes Setup.exe to uninstall a previously installed product.

/j: Advertise mode

The /j option causes Setup.exe to perform an advertised installation. An advertised installation creates shortcuts, registers COM servers, and registers file types, but does not install your product's files until the user invokes one of these "entry points."

/debuglog: Installation logging

To specify the name and location of the log file, pass the path and name, as in the following example: Setup.exe /debuglog"C:\PathToLog\setupexe.log"

To generate a log file for the feature prerequisites in the installation, use the /v parameter to set the ISDEBUGLOG property to the full path and file name for the log file, as follows:

Setup.exe /debuglog"C:\PathToSetupLogFile\setup.log" /v"ISDEBUGLOG=prereq.log"

You can use directory properties and environment variables in the path for the feature prerequisite log file.

/hide_progress: Suppress all progress dialogs

Suppresses the display of any small and standard progress dialogs that might be shown during initialization.

The small progress dialog is usually used for installations that display a splash screen during initialization, since a standard-size progress dialog does not leave any space for the splash screen. Specifying the /hide_progress option hides the small progress dialog for those installations, so end users would see just the splash screen without any progress indication.

For command line arguments of the MSI package please refer to Microsoft's documentation for Windows Installer.

Note

The Setup.exe and the .msi package support different command line arguments. When running the setup silently the appropriate argument has to be specified for both setup.exe and .msi.

Note

When running the setup silent from command line, all features and dependent have to be specified manually in the ADDLOCAL property. The dependent features are automatically selected when using the setup with user interface.

BVMS - Deployment guide 15 of 16

Note

There are different user interface levels for running the msi:

/qn: Displays no user interface.

/qb: Displays a basic user interface.

/qr: Displays a reduced user interface with a modal dialog box displayed at the end of the installation.

/qf: Displays the full user interface with a modal dialog box displayed at the end.

/qn+: Displays no user interface, except for a modal dialog box displayed at the end.

/qb+: Displays a basic user interface with a modal dialog box displayed at the end.

/qb-: Displays a basic user interface with no modal dialog boxes.

If the UI sequence of the main installation's .msi package is skipped by using "/qn", the setup launcher evaluates Windows Installer properties such as ADDLOCAL,

Note

If the UI sequence of the main installation's .msi package is skipped by using "/qn", the setup launcher evaluates Windows Installer properties such as ADDLOCAL, ADDSOURCE, ADDDEFAULT, and ADVERTISE to determine if any feature prerequisites should be installed, and it installs feature prerequisites accordingly.

Note

When running the setup completely silent, the system reboots unasked at the end of the installation.

Note

Some prerequisite installations (e.g. .NET framework) may also reboot the system unasked. The setup will usually resume after restart.

BVMS - Deployment guide 16 of 16

11 Examples

The following examples can be used to install the related components silently. The texts can be copied into a batch file for re-use.

Operator Client silent setup

Setup.exe /s /v"/qn ADDLOCAL=Core,Client,BVMSSDK,ConfigCollector,VSDK,ExportPlayer"

BVMS SDK silent setup

Setup.exe /s /v"/qn ADDLOCAL=BVMSSDK,ConfigCollector"

All-in-one silent setup

Setup.exe /s /v"/qn ADDLOCAL=Core,Client,BVMSSDK,ConfigCollector,VSDK,ExportPlayer"

CameoSDK silent setup

Setup.exe /s /v"/qn ADDLOCAL=Core,CameoSDK,CameoSDKManuals,BVMSSDK,ConfigCollector,VSDK"

VSG silent setup

Setup.exe /s /v"/qn ADDLOCAL=VSG"

MVS silent setup

Setup.exe /s /v"/qn ADDLOCAL=Core, MVS, BVMSSDK, ConfigCollector, VSDK CONFIGUREIIS=1"

Management server silent setup

Setup.exe /s /v"/qn ADDLOCAL=Core,Server,SQL_Server,BVMSSDK,ConfigCollector,VSDK,ExportPlayer"

Configuration Client silent setup

Setup.exe /s /v"/qn ADDLOCAL=Core,ConfigClient,BVMSSDK,ConfigCollector,VSDK"